

Topic: ITA AIRWAYS ULD AIRCRAFT LOADING

Dear All,

This R&S to remind you that, except for A220 aircraft and A320Neo – registration EI-INA/NB/NC/ND/NE, the rest of narrow body fleet (A319 and A320) are containerized aircraft.

As stated in HLM, it is forbidden to load bulk in FWD and AFT Hold. Let me also highlight that in the containerized aircraft there are not Door-Net to protect cargo door. So, to load belly items put the aircraft at risk, because the bags can move in flight due to the take-off acceleration or for weather condition.

For any reason the load controller can decide to change the cargo configuration.

In the event of lack of container all bags must be loaded in Compartment 5, that is the only section where to load bulk items.

Please remember that the position in front the door **MUST** be always occupied.