

## SAFE AIRCRAFT HANDLING PRACTICES – A320 Carpatair Loading Instruction

**Purpose:**

This bulletin is issued to highlight recent weight and balance (W&B) discrepancies in aircraft documentation and calculations. These discrepancies have the potential to compromise flight safety.

The compartments for Carpatair A320 YR-ABC, operating for airBaltic, are located as follows:

→ Forward hold: CPT1

→ AFT hold: CPT3 CPT4 CPT5

Read and Signed confirmation shall be sent to [Ground\\_DOC@airbaltic.com](mailto:Ground_DOC@airbaltic.com)

LOADING INSTRUCTION/REPORT		PREPARED BY Kristaps Krumins EDNO			
ALL WEIGHTS IN KG		1			
FROM/TO FLIGHT	A/C REG	VERSION	GATE TARMAC	DATE	TIME
LIS RIX BT676	YR-ABC	A320-216		20JUN25	1623
PLANNED JOINING LOAD					
RIX	C 4	Y 134	C 0	M 20	B 914
JOINING SPECS: SEE SUMMARY					
TRANSIT SPECS: SEE SUMMARY					
RELOADS:					
ACTUAL PIECES WEIGHT					
LOADING INSTRUCTION					
*****					
CPT 1	MAX 03402				
:1	:				
:NO FIT	:				
:	:				
:	:				
CPT 1 TOTAL:					
FWD					
*****					
CPT 3	MAX 01301				
:3	:				
:ONLOAD: RIX BT R/	:				
: 252/16PCS*	:				
: M/20	:				
:SPECS: NONE	:				
:REPORT:	CPT 3 TOTAL:				
*****					
CPT 4	MAX 03235				
:4	:				
:ONLOAD: RIX BF R/	:				
: 48/3PCS*	:				
: BB R/	:				
: 614/39PCS*	:				
:SPECS: NONE	:				
:REPORT:	CPT 4 TOTAL:				
*****					
CPT 5	MAX 01497				
:5	:				
:NO FIT	:				
:	:				
CPT 5 TOTAL:					
*****					