

## WINTER OPERATIONS - GPU, Heating and Water/WC draining A220-300

+5°C till +1°C			0°C till -10°C			≤ -10°C		
Water drain	Interior heater	GPU	Water drain	Interior heater	GPU	Water drain	Interior heater	GPU
Not required	Not required	Always connected	Not required	Not required	Always connected	Not required	Per Crew Request	Always connected
Not required	Not required	Disconnect when crew leaves and connect 1hour before STD	Not required	Required only if airBaltic owned heater is available	Required if heater not connected (GPU to be used in Ground Service Mode - BT GOM D.1.5.3)	Required if local regulations allow and only with supervision by BT Technicians	Required	Required if water draining not possible (GPU to be used in Ground Service Mode - BT GOM D.1.5.3)

NOTE: If water is drained it must be uplifted before GPU is connected