

Loading Info	
Local Baggage	pcs
TRS Baggage	pcs
BUGGY , DAA, WCH, GATE Baggage	pcs
RUSG Baggage	pcs
TOTAL Pcs. Loading	pcs

Special Load Instructions / Özel Yük Talimatları	
(AVI, WEA, HEA, HUM, DAA, etc) / (Kedi / Köpek / Ağır Yük, Cenaze, Teknik Malzeme, vs.)	
H1 40BY H2 CGO + HUM H3 120BY/BT H4 Rest Bags	
148 BY LDD H1/H3/H4 32 BT LDD H3/H4 07 CGO LDD H2 01 HUM LDD H2 NOTOC YES	

Note:	
Note: AVIH FWD Hold, Weapon Hold 1, Crewbaggage must be loaded Hold 5.	
Not: AVIH on ambara, Silah Hold 1'e, Ekip bagajı Hold 5'e yüklenmelidir.	

Load Planner(Operasyon Agent) / Operasyon Memuru	
This form filled in accordance with AHM, DGR and company regulations. / Bu form AHM DGR ve şirket düzenlemelerine uygun olarak düzenlenmiştir.	
Name Surname / Ad Soyad	Signature / İmza

Loading Team Leader / Yükleme Sorumlusu	
This aircraft has been loaded in accordance with these instructions including the deviations recorded and cargo holds height limitations (6cm). The load has been secured in accordance with company regulations / Bu uçak, yükleme formatında yer aldığı şekilde ve ambar yükseklik limitlerine (6cm) uygun olarak yüklenmiştir. Havayolu kurallarına göre yükler emniyet altına alınmıştır.	
Name Surname / Ad Soyad	Signature / İmza

Station	Flight No	A/C Reg	STD (Local Time)	From	Via	To/Dest	Date
FRA	996	TC-RDE	17:35	-	-	SAW	30/04/2026

	AFT HOLD / ARKA AMBAR			FWD HOLD / ON AMBAR	
AT ARRIVAL GELEN YÜK	5 FRA AFT DOOR	4 FRA AFT DOOR	3 FRA	2 FRA FWD DOOR	1 FRA FWD DOOR
LOADING INSTRUCTION YÜKLEME TALIMATI	5 SAW NIL AFT DOOR	4 SAW 08 BY REST BT AFT DOOR	3 SAW 100 BY 20 BT AFT DOOR	2 SAW ALL CGO ALL HUM FWD DOOR	1 SAW 40 BY FWD DOOR
ACTUAL LOADING GERÇEKLEŞEN YÜKLEME	5 SAW AFT DOOR	4 SAW AFT DOOR	3 SAW	2 SAW FWD DOOR	1 SAW FWD DOOR

Remarks / Açıklamalar	
Please Fill In The Checklist (RAMP)/ Lütfen Kontrol Listesini Doldurunuz (RAMP)	

Any defects of cargo holds, nets, and locks must be reported to the captain and PGT Ground Ops Department. Relevant LIR, LS, and GSR forms must be sent to PGT Ground Ops Department. / Kargo ambarları, ağırları ve kilitlerine ilişkin herhangi bir hasar, mesul kaptana ve PGT Yer İşletme Departmanı'na rapor edilmelidir. İlgili LIR, LS ve GSR formu PGT Yer İşletme Departmanı'na gönderilmelidir.	<input type="checkbox"/> Check <input type="checkbox"/> N/A	Cargo holds have been checked for any unsecured items after offloading completed, and cargo hold nets and locks have been checked, fitted, and secured after loading completed. / Ambar boşaltıldıktan sonra güvenlik riski yaratabilecek unsurlar için kontrol edilmiş ve yükleme tamamlandıktan sonra ambar ağırları ve kilitleri kontrol edilmiş ve güvenli bir şekilde bağlanmış/kilitlenmiştir.	<input type="checkbox"/> Check <input type="checkbox"/> N/A
--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------

See Pegasus AHM560 for hold weight limitations via online library./ Ambar KG kapasitesi için online kütüphaneden Pegasus AHM560' a bakınız.