

ALTEA FM MOBILE RAMP

airBaltic



AIRBALTIC GROUND OPERATIONS
2021, JANUARY

- Flight Management Mobile is a web-based application designed for use on hand-held tablet computers or cell phone, which is used to communicate information to the Load Controller assigned to the flight in Flight Management
- Flight Management Mobile allows the Ramp agent to perform the following tasks:

Ramp

- ✓ Display the load distribution prepared by the Load Controller.
- ✓ Communicate final load distribution to the Load Controller.
- ✓ Move deadload or baggage.
- ✓ Modify deadload or baggage details.
- ✓ Display the baggage variation.
- ✓ Display DG/SL information.
- ✓ Ramp clearance.
- ✓ Display or send documents or messages related to the flight.
- ✓ Send or receive messages related to the flight.

Flight Information

- ✓ Display a summary of the flight.
- ✓ Update the aircraft location.
- ✓ Display potable water weight.
- ✓ Display the balance conditions of the aircraft.

ACCESS TO APPLICATION

airBaltic

- Before you can log in to Flight Management Mobile, the Security Administrator for airBaltic must define your access level and your rights to allow you to perform specific functions in the application.




Your Security Administrator will provide you with a **user ID**.

- The **latest version** is always available to all users.

TOUCH GESTURES

Action	Description	Example Usages
Single-tap	Touch the surface rapidly once with your fingertip.	<ul style="list-style-type: none">• Display the Ramp screen for a flight from the flight search results.• Select a field, bay/pallet position, compartment, hold.• Activate the buttons (Save, Refresh, Update, Send).• Activate the dropdown main menu.
Double-tap	Touch the surface rapidly twice with your fingertip.	Display dialogue boxes, such as: <ul style="list-style-type: none">• Deadload Details• Modify Commodity
Flick or Swipe	Flick (fast) or swipe (slowly) your fingers on the screen.	<ul style="list-style-type: none">• Scroll a list of flights.• Move around the aircraft hold display.
Pinch or Spread	Place your thumb and a finger (or two fingers) on the screen and move them together or apart without lifting them from the screen.	Zoom in or out. Note: For small devices only.

MENU BAR BUTTONS

Button	Explanation
	<p>Save</p> <p>Saves the changes you have made to the flight and makes them visible to the Load Controller. Your changes to a flight are not finalised until you have successfully saved them.</p> <p>Note: Changes you make to the load distribution may cause a change of load control status, which requires the Load Controller to reapprove the distribution.</p>
	<p>Manual Refresh</p> <p>Refreshes the data displayed on your screen with changes made by the Load Controller. For example, to display the latest distribution or flight statuses for your flight.</p> <p>Allows you to ignore the changes you have made since the last Save.</p>
	<p>Automatic Refresh</p> <p>Automatically refreshes the data displayed on your screen with changes made by the Load Controller, at a time interval determined by your administrator.</p> <p>The refresh time interval is reset after an automatic refresh, a manual refresh, or a save.</p> <p>It is unavailable when you are performing actions, or have unsaved changes on your flight, when the button returns to Manual Refresh.</p>

CONTACT DETAILS

Your contact details are displayed when you log in, and when you select **Profile** from the main menu.

- Make any necessary updates to your contact details for your current login.
- In the **Role** drop-down list select Ramp Agent
- Use **Night Mode** to apply dark theme
- Tap **Done**.

Night Mode ☐


Contact Details for JPRANCA

First Name	<input type="text" value="Jana"/>	Surname	<input type="text" value="Pranca-Milberga"/>
Phone	<input type="text" value="371"/> <input type="text" value="26"/> <input type="text" value="245678"/>	Fax	<input type="text"/> <input type="text"/> <input type="text"/>
Printer	<input type="text"/>	Radio ID	<input type="text"/>
• Role	<input type="text" value="Ramp Agent"/>	<input type="button" value="Done"/>	

MAIN MENU

The options displayed on the main menu vary according to your role and the conditions of your active flight.

- Tap the menu symbol to display the main menu.
- Tap an option to select it.



OPTIONS	ALLOWS YOU TO:
PROFILE	Update your contact details, such as printer address, and radio ID.
SEARCH	Enter details of the flight you want to work on.
MESSENGER	Display messages related to your flight. Communicate with the Load Controller for the flight.
RAMP	Perform ramp tasks, such as confirming baggage number of pieces or deadload weights, and ramp clearance.
DOCUMENTS	Display or send a document or message for the selected flight.
FLIGHT INFORMATION	Display details of the flight, including predicted underload, potable water, and balance conditions.
CONTACTS	Display contact details of the Load Controller, and add yourself as Ramp Agent for the flight.
REPORT ISSUE	Generate a log file that can be used by Amadeus to investigate software issues.
LOGOUT	Log out of Flight Management Mobile.

* Freight, Passenger, About – not applicable on flight handling for BT

FLIGHT SEARCH

airBaltic

- In the **Flight Search** panel, enter details of the flight or flights you wish to display.
- Using the pop-up calendar, select a specific date, or clear the date to search for flights without using a specific date.
- Enter the mandatory **Carrier** and **Departure Port** fields (all other fields are optional).

*Carrier	Flight No	Flight Date	*Depart	Arrive	Registration	Search
BT	139	03-JUL-2020	RIX			

- Tap **Search**. Flights are displayed in order of departure.

<input type="checkbox"/>	FLIGHT	DATE	DEP	ARR	TIME	STATUS	AIRCRAFT	LOCATION	LOAD CONTROLLER
<input checked="" type="checkbox"/>	BT 493	03-JUL-2020	RIX	SPU	S08:30	GO-RO-LC-AC-BO	A220-300 A YL-CSI	GTE C7 (Gate)	Guntars Krukovskis +371 29442260
<input checked="" type="checkbox"/>	BT 343	03-JUL-2020	RIX	VNO	S12:15	GO-RN-LO-AO-BN	A220-300 A YL-CSK		Guntars Krukovskis +371 29442260
<input checked="" type="checkbox"/>	BT 251	03-JUL-2020	RIX	HAM	S12:40	GO-RN-LO-AO-BN	A220-300 A YL-CSE		Guntars Krukovskis +371 29442260
<input type="checkbox"/>	BT 315	03-JUL-2020	RIX	TLL	S14:40	GO-RN-LO-AO-BN	A220-300 A YL-CSH		Guntars Krukovskis +371 29442260
<input type="checkbox"/>	BT 633	03-JUL-2020	RIX	FCO	S14:50	GO-RN-LO-AO-BN	A220-300 A YL-CSJ		Guntars Krukovskis +371 29442260

- Tap the flight you want to display. The flight is displayed on the Ramp screen.

SUBSCRIPTION TO A FLIGHT

airBaltic

Subscribe to Messenger for a flight to send/receive messages:

- In the Flight Search results, select the option on the left-hand side of each flight.
- To select all flights, select the option on the left-hand side of the header row.
- To subscribe to the selected flight or flights, tap **Subscribe**.
- To add your details to the flight or flights and subscribe as well, tap **Add & Subscribe**.
- Tap **OK** to continue.

*Carrier	Flight Number	Flight Date	*Departure Port	Arrival Port	Registration	Search
BT		15-OCT-2020	LGW			


<input type="checkbox"/>	FLIGHT	DATE	DEP	ARR	TIME	STATUS	AIRCRAFT	LOCATION	LOAD CONTROLLER
<input checked="" type="checkbox"/>	BT 650	15-OCT-2020	LGW	TLL	S14:55	GO-RN-LC-AO-BN	A220-300 A YL-CSA		Guntars Krukovskis +371 29442260
<input checked="" type="checkbox"/>	BT 654	15-OCT-2020	LGW	RIX	S17:35	GO-RN-LO-AO-BN	A220-300 A YL-AAO		Guntars Krukovskis +371 29442260
<input type="checkbox"/>	BT 652	15-OCT-2020	LGW	RIX	S09:25 A09:38	GD-RF-LSF-AF-BC	A220-300 A YL-CSI	GTE 53 (Gate)	Guntars Krukovskis +371 29442260

Subscribe

Add & Subscribe

ADDING YOURSELF TO A FLIGHT

Adding yourself to a flight makes your contact details available to the Load Controller and other agents assigned to the flight.

- Search for and display the flight.
- On the main menu, tap **Contacts**.
- To add your details from the **Profile** screen for the current flight, tap **Add Self** for the role you selected after login.
- To add details of another person, tap **Edit**, fill in the details, then tap **Done**.
- Tap  to save.

TYPE	FIRST NAME	SURNAME	PRINTER	WORKSTATION / RADIO ID	PHONE	
Ramp Agent	ROBERTS	SKRIVERIS			00 371 29442260	Add Self Edit
Load Controller	Kalvis	Kauss				
Fuel Agent						
Freight Agent						

ALLOCATION TO A FLIGHT

Allocate Yourself to a flight:



- Find a Flight.
- In the Flight Search results, select the checkbox against the flight, then tap **Allocate**.
 - When allocated to the flight as Ramp Agent:**
 - ✓ You can make updates on the Ramp screen.
 - ✓ Your details are entered into the Contacts screen.
 - ✓ You are subscribed to messages for the flight.
- Tap the flight you want to display.
- When you are no longer responsible for a flight, unallocate yourself.

*Carrier	Flight Number	Flight Date	*Departure Port	Arrival Port	Registration	
BT		27-JAN-2021	TLL			<input type="button" value="Search"/>

<input type="checkbox"/>	FLIGHT	DATE	DEP	ARR	TIME	STATUS	AIRCRAFT	LOCATION	LOAD CONTROLLER
<input checked="" type="checkbox"/>	BT 195	27-JAN-2021	TLL	CPH	S16:05	GO-RN-LO-AO-BN	A220-300 A YL-CSF	GTE 08 (Gate)	Kalvis Kauss
<input type="checkbox"/>	BT 318	27-JAN-2021	TLL	RIX	S21:10	GO-RN-LO-AO-BN	A220-300 A YL-CSF	GTE 08 (Gate)	Kalvis Kauss

Note: Only one Ramp Agent can be allocated to a flight at the same time.

FLIGHT DROP-DOWN MENU

- To switch between your open flights:
 - ✓ Tap  on the flight status bar to display a drop-down menu of your open flights.
 - ✓ Tap the flight you want to display.
- To close a flight tap  on the status bar.



FLIGHT STATUS BAR

airBaltic

The status bar displays a summary of the flight leg. It is displayed at the top of all screens when you have a flight open.

1 Close flight icon

2 Flight number

3 Flight date

4 Departure and arrival ports

5 Aircraft registration

6 Time of departure

7 Edition of the Loading Instruction Report (LIR)

8 Status bar

9 Drop-down menu of open flights



FLIGHT INFORMATION SCREEN

airBaltic

- To display detailed flight information, tap or select **Flight Info** from the menu.
- To return to the previous screen, tap **Back to Ramp** (or **Back to Passenger**, **Back to Documents**).


- 1 Flight number
- 2 Flight date
- 3 Departure and arrival ports
- 4 Time of departure
- 5 Flight status info
- 6 Aircraft registration
- 7 Aircraft subtype
- 8 Aircraft location
- 9 Document info
- 10 Predicted underload
- 11 Accepted passengers
- 12 Cabin configuration

Flight Flight Number: BT 223 1 Flight Date: 17-AUG 2 Routing: RIX-MUC 3 STD: 17:00 4 Status: GO - RF - LSF - AF - BC 5	Aircraft Registration: YL-CSJ 6 Subtype: A220-300 A 7 Aircraft Location: <input type="text" value="GTE"/> <input type="text" value="B6"/> 8	Documents LIR 1 - OFP 0 - NOF 0 - FLT 1 9 Potable Water Weight: 0
Load Predicted Underload: 7 066 kg 10	Balance Conditions AFT LIZFW 48.59 33.47 16.85 LITOW 46.89 35.14 15.4	
Passenger Accepted: 116 + 1 11 Saleable Config: 8C/135Y 12		



BALANCE CONDITIONS

airBaltic

- ① Zero fuel weight (ZFW) balance conditions.
- ② Aft ZFW index limit.
- ③ Actual ZFW limit.
- ④ Forward ZFW limit.
- ⑤ Takeoff weight (TOW) balance conditions.
- ⑥ Aft TOW index limit.
- ⑦ Actual TOW index.
- ⑧ Forward TOW limit.



AIRCRAFT LOCATION

- Search for and display the flight.
- Tap  to display the Flight Information screen.
- In the **Aircraft Location** field, enter the gate identifier and gate number.
- Tap  to save.

Aircraft	
Registration:	YL-AAR
Subtype:	A220-300 A
Aircraft Location:	<div>GTE</div> <div>B6</div>













RAMP SCREEN

airBaltic

- 1 Hold description and remaining weight allowance.
- 2 Compartment description and remaining weight allowance.
- 3 Hold or compartment weight-used indicator.
- 4 Bulk hold position.
- 5 Total gross weight per position.
- 6 Number of baggage pieces per position.
- 7 Aircraft door.

of 2606 kg)		FWD (970 of 2446 kg) 1	
CPT 3 (854 of 1858 kg) 2		3 CPT 2 (814 of 1646 kg)	CPT 1 (156 of 800 kg)
kg 854	53 3	kg 814	30 2 kg 156
OSL		OSL	
BF 2	R 8	BB 10	8
BB 26	R 8	BT 20	9
BT 25	R 9	M 327 kg	99
		C 0 kg	99
		4	
			BB 10 8
			7

SYMBOLS IN THE AIRCRAFT HOLD

Symbol	Description
	Destination.
	Baggage commodity, number of pieces.
	Baggage rest location.
	Baggage finalised indicator.
	Commodity identifier and weight.
	Priority indicator.
	Estimated indicator.
	Transit indicator.
	DG/SL indicator (displayed below the commodity).
	Additional DG/SL indicator.
	Additional commodity indicator.
NIL	Empty bulk hold indicator.
	Unserviceable bulk position (non-containerised aircraft).


TABS ON RAMP SCREEN


- These tabs are displayed on the right-hand side of the screen.
- Tap the arrow icon below the tabs to expand or collapse them.

Move Mode	Move
Ramp Clear Mode	Ramp Clear
Zoom Mode	Zoom
Offload List (0)	Off (0)
Supplementary Information (0)	SI (0)
Baggage Variation	Bag Var

TAB	ALLOWS YOU TO:
MOVE MODE	Move deadload between compartments.
RAMP CLEAR MODE	Confirm each position in an a/c has been loaded accordingly.
ZOOM MODE	Display the hold layout of the entire a/c.
OFFLOAD LIST	View number of commodities currently offloaded for this flight.
SUPPLEMENTARY INFORMATIONS	Display or update supplementary information. (LIR, LDM, OIR)
BAGGAGE VARIATION	Display difference between the baggage values provided by the check-in application and final baggage values reported.

MOVING DEADLOAD

- Display the **Ramp** screen for the flight.
- Tap **Move**.
- Double-tap the position containing the commodity you want to move.
- Tap the commodity in the Details panel.
- Tap the new position in the aircraft hold.
- To move all the weight (including any DG/SLs), tap **Move All**.
- To move only some of the weight:
 - ✓ Enter the weight to move.
 - ✓ Select the DG/SLs you want to move with the weight.
 - ✓ Tap **Move**.
- Tap  to save.



The screenshot displays the 'Ramp' screen for flight BT 361 on 18-SEP, route RIX-TLL YL-AAR, STD 23:15, LIR 1, GO-RO-LC-AO-BN. The interface is divided into three main sections: CPT 3 (1064 of 1858 kg), FWD (0 of 2446 kg), and CPT 1 (0 of 800 kg). The CPT 3 section shows a details panel for TLL with two commodities: M (357 kg, 99) and C (707 kg, 99). The FWD and CPT 1 sections are currently empty. On the right side, there is a vertical toolbar with buttons: Move, Ramp Clear, Zoom, Off (0), SI (0), and Bag Var. A red circle highlights the 'Move' button in the top right corner of the screen.

Position	Weight (kg)	Details
CPT 3 (1064 of 1858 kg)	1064	<ul style="list-style-type: none">M 357 kg 99C 707 kg 99
FWD (0 of 2446 kg)	0	
CPT 1 (0 of 800 kg)	0	

RAMP CLEARANCE

- Display the flight on the **Ramp** screen.
- To enter ramp-clear mode, tap **Ramp Clear**.

The **Ramp Clear** tab becomes green.


All positions that can be ramp cleared are highlighted in blue.

- To ramp clear:
 - ✓ **A position:** Tap on the position.
 - ✓ **A compartment:** Tap on the compartment indicator.
 - ✓ **A hold:** Tap on the hold indicator.


Ramp-cleared positions are indicated with a green tick (check mark).

- Tap  to save.

Ramp Clear Before Save



Ramp Clear After Save





DEADLOAD DETAILS

- To Display Deadload Details:
 - ✓ Display the Ramp screen for the flight.
 - ✓ Double-tap the position you want to display.

The selected position is highlighted in orange.

Deadload details are displayed in the Details panel on the right-side of the screen.

 - ✓ Tap  to close the Details panel and deselect the position.
- Tap **Zoom** to display the hold layout of the entire aircraft.



DANGEROUS GOODS

- Display the **Ramp** screen for the flight.
- Double-tap the position of the ULD or bulk containing the DG/SLs.


The selected position is highlighted in orange, and the **Details** panel is displayed on the right-side of the screen.


- Tap the DG/SL symbol.

The **View DG/SLs** window is displayed.

- Double-tap a DG/SL to display its details.

Note: Scroll when there are many DG/SLs to display.

- Tap **Cancel** to the **Details** panel.
- Tap  to close the **Details** panel.



View DGSLs						
DG/SL IMP CODE	WEIGHT	AIRWAYBILL NO.	NO. OF PACKAGES	QUANTITY / TI	UN/ID NO.	RRR CATEGORY
RFL	1	657-12933255	1	1L	1866	

DOCUMENTS SCREEN

- 1 Document Display panel - displays the content of the selected document.
- 2 Documents List panel - displays all available documents for the flight.

The screenshot shows the airBaltic Documents Screen interface. The top header bar is blue and contains the airBaltic logo, a menu icon, and flight information: BT 343, 16-SEP, RIX-VNO, YL-CSN, STD 12:15, LIR 1, GO-RO-LC-AC-BO. Below the header, the interface is split into two main sections. The left section, labeled '1', is the 'Document Display panel' showing a detailed loading instruction report for flight BT 343. The right section, labeled '2', is the 'Documents List panel' showing a list of available documents for the flight.

Document Display Panel (1):

LOADING INSTRUCTION/REPORT PREPARED BY Lauris Abols EDNO 1
ALL WEIGHTS IN KG
FROM/TO FLIGHT A/C REG VERSION GATE TARMAC DATE TIME
RIX VNO BT343 YL-CSN A220-300 A 16SEP20 1015
PLANNED JOINING LOAD
VNO C 0 Y 25 C 0 M 1628 B 100
JOINING SPECS: SEE SUMMARY
TRANSIT SPECS: SEE SUMMARY
RELOADS:

LOADING INSTRUCTION ACTUAL PIECES WEIGHT

CPT 1 MAX 00800
:1 :
:ONLOAD: VNO M/150 :
:SPECS: NONE :
:REPORT: CPT 1 TOTAL: *****

CPT 2 MAX 01646
:2 :
:ONLOAD: VNO M/750 :
:SPECS: NONE :
:REPORT: CPT 2 TOTAL: *****

CPT 3 MAX 01858
:3 :
:ONLOAD: VNO M/728 :
:SPECS: NONE :
:REPORT: CPT 3 TOTAL: *****

CPT 4 MAX 01055

Documents List Panel (2):


Docs
Loading Report (1)
Load Instruction Report (1)
Forecast ZFW Message (3)
SI (0)
Send To

PRINTING





To Send/Print a Document or Message:


- Display the document you want to send.
- Tap **Send To**.

The default addresses are preselected.

- Review, select and if necessary, update the addresses where you want to send the document.
- Tap **Send**.
- Tap  to close the **Details** panel.

RIX-VNO YL-CSN STD 12:15 LIR 1 GO-RO-LC-AC-BO





Load Instruction Report

☐ Location

Airport

▼

Terminal

▼

GTE

▼

☐ TTY

☐ Printer☒ Email

test@test.net

Send

Docs

Send To

SI (0)

SUPPLEMENTARY INFORMATION

- Search for and display the flight.

The **SI** tab indicates the number of documents that have SI text attached.

- Tap **SI**.
- The **LIR** (Loading Instruction Report) tab is displayed.

The upper part of the panel is pre-filled with DG/SL comments, followed by SI text considered relevant for the Ramp Agent.

- To enter SI text for current version of another document type, tap the tab of the document type in which you want to enter supplementary information:
 - ✓ **LDM** (Load Message).
 - ✓ **OIR** (Offload Instruction Report).

The **i** icon is displayed in the tab header when SI text is stored for the document type.

- Tap **X** to close the Supplementary Information panel.

The screenshot shows a mobile application interface for entering supplementary information. At the top, there is a close button (X) and a tab bar with four tabs: LIR (selected, with an information icon), LDM, OIR, and CPM. The main content area is divided into two sections. The top section is labeled 'Dangerous Goods/Special Load comments' and contains the text 'AVI/1'. The bottom section is a large text input area. Below the input area, there is a blue bar with three dots. Below this bar, there is a row of checkboxes: LIR (checked), LDM (checked), OIR (unchecked), and CPM (unchecked). Below the checkboxes, there is a text input area labeled 'TEXT FOR MULTIPLE DOCUMENTS'. At the bottom of the panel, there is a status bar with the text '(LIR 223, LDM 223, OIR 223, CPM 223 remain)'. At the very bottom, there are two buttons: 'Reset' and 'Append'.

Close button (X)

Tab bar: LIR (selected), LDM, OIR, CPM

Dangerous Goods/Special Load comments

AVI/1

(250 remain)

... (three dots)

Checkboxes: ☒ LIR, ☒ LDM, ☐ OIR, ☐ CPM

TEXT FOR MULTIPLE DOCUMENTS



(LIR 223, LDM 223, OIR 223, CPM 223 remain)


Reset button

Append button

SUPPLEMENTARY INFORMATION

Optional. To append supplementary text to multiple messages or for future versions of the document:

- Tap .
- The **Append** options are displayed.
- Select the message types.
- Enter the text in the text box on the lower part of the screen.
- Tap **Append**.
- Tap  to close the Supplementary Information panel.



The screenshot shows a mobile application interface for entering supplementary information. At the top, there's a close button (X) and a tab bar with four options: LIR (selected), LDM, OIR, and CPM. Below the tabs is a large text area for "Dangerous Goods/Special Load comments" with the example text "AVI/1". A "(250 remain)" indicator is at the bottom right of this area. Below this is a blue bar with three dots. Underneath is a row of checkboxes for selecting message types: LIR (checked), LDM (checked), OIR (unchecked), and CPM (unchecked). Below the checkboxes is a text box labeled "TEXT FOR MULTIPLE DOCUMENTS". At the bottom, there are two buttons: "Reset" and "Append". A "(LIR 223, LDM 223, OIR 223, CPM 223 remain)" indicator is at the bottom right of the text box area.

MESSENGER

airBaltic

To Send a Message:

- Tap  for your active flight or tap **Messenger** on the main menu, then tap the flight leg.

The **Messenger** window is displayed.

- In the text box at the bottom of the **Messenger** window, type your message.
- Select the recipient of the message:
 - ✓ Load Controller
 - ✓ Check-in Agent
 - ✓ Supervisor
- Tap **Send**.
- To return to your flight, tap **Ramp** on the main menu.

Note: To receive or send messages, you must first subscribe to or allocate yourself to a flight.

BT 603 16-SEP RIX

PROCESSEDLOW PRIORITY11-Sep-2020 13:25:07 UTC

Flight created

SENTVERY HIGH PRIORITY16-Sep-2020 10:30:19 UTC

To LC: Hello!

SENTVERY HIGH PRIORITY16-Sep-2020 10:32:01 UTC

To LC: Please send Loading Instruction

PROCESSEDVERY HIGH PRIORITY16-Sep-2020 10:35:20 UTC

Test

PUBLISHEDMEDIUM PRIORITY16-Sep-2020 10:37:23 UTC

Baggage Variation created: BRU, BB, +7 pcs, +99 kg.

PUBLISHEDMEDIUM PRIORITY16-Sep-2020 10:37:23 UTC

Baggage Variation created: BRU, BT, +1 pcs, +16 kg.

Send to: ☒ LOAD CONTROLLER ☐ CHECK-IN AGENT ☐ SUPERVISOR

Send

Close

MESSENGER WINDOW

airBaltic

- 1 A list of the flights you have subscribed to. Tap on the flight to select it.
- 2 Messages received for the selected flight.
- 3 Tap **Refresh** to ensure you can view the most recent messages.
- 4 Message text box for sending messages.

Refresh 3

BT 603 16-SEP RIX 1

BT 603 16-SEP RIX

PROCESSED LOW PRIORITY 11-Sep-2020 13:25:07 UTC

Flight created

SENT VERY HIGH PRIORITY 16-Sep-2020 10:30:19 UTC

To LC: Hello! 2

SENT VERY HIGH PRIORITY 16-Sep-2020 10:32:01 UTC

To LC: Please send Loading Instruction

PROCESSED VERY HIGH PRIORITY 16-Sep-2020 10:35:20 UTC

Test

PROCESSED MEDIUM PRIORITY 16-Sep-2020 10:37:23 UTC

Baggage Variation created: BRU, BB, +7 pcs, +99 kg.

PROCESSED MEDIUM PRIORITY 16-Sep-2020 10:37:23 UTC

Baggage Variation created: BRU, BT, +1 pcs, +16 kg.

Send to: ☒ LOAD CONTROLLER ☐ CHECK-IN AGENT ☐ SUPERVISOR

4

Send

THANK YOU!

TOGETHER WE MAKE SURE THE
TRAVEL IS SAFE AND HEALTHY

