



LOADING INSTRUCTIONS
ISTRUZIONI PER IL CARICO

A321

LOAD CONFIGURATION

CLS (Cargo Loading System) installed

Up to n.10 AKH / PKC

FLIGHT NR

A/C REG

DATE

STATION

DESTINATIONS

PREPARED BY

**LOAD DISTRIBUTION
AT ARRIVAL**

53	52	51	42	41	33	32	31

23	22	21	12	11

**LOADING
INSTRUCTIONS**

CMPT5 (BULK)-Max Load 800kg

CMPT3 + CMPT4 - Max Load 5670 kg (*)

CMPT1 + CMPT2 - Max Load 5670 kg (*)

53	52	51	42	41	33	32	31
MGW: 411kg	MGW: 187kg	MGW: 374kg	Max Load 1134 kg (*)	Max Load 1134 kg (*)	Max Load 1134 kg (*)	Max Load 1134 kg (*)	Max Load 1134 kg (*)

23	22	21	12	11
Max Load 1134 kg (*)	Max Load 1134 kg (*)	Max Load 1134 kg (*)	Max Load 1134 kg (*)	Max Load 1134 kg (*)

Max Floor Loading:
CMPT1,2,3,4 (kg/m²) **488**
CMPT5 (kg/m²) **732**

(*)including pallet or container tare weight

**LOAD DISTRIBUTION
AT DEPARTURE**

53	52	51	42	41	33	32	31

23	22	21	12	11

SPECIAL INSTRUCTIONS (including any anomalies evidenced - *include eventuali anomalie riscontrate*)

This aircraft has been loaded in accordance with these instructions including the deviations shown on the "LOAD DISTRIBUTION AT DEPARTURE". The load has been secured in accordance with Company Regulations.

Il carico di questo aeromobile è stato effettuato secondo le istruzioni del presente modulo. Le eventuali variazioni apportate sono state registrate nel riquadro "LOAD DISTRIBUTION AT DEPARTURE". Il carico è stato ancorato secondo le norme di Compagnia.

CARGO COMPARTMENT VISUAL CHECK PERFORMED

I undersigned assure that the aircraft has been loaded as per these instructions (signature of loading supervisor or person responsible for loading)

Captain signature for acceptance